

# Nellie's<sup>®</sup>

## DISH STICK

BÂTONNET À VAISSELLE



The **Dish Stick** is the perfect combination of our **Dish Butter** and **Forever Brush**, with the semi-solid soap built right into the brush! Need more soap? Just twist the bottom of the handle to move it on up. To replace the soap, simply twist off the brush head and add a fresh refill stick.

Convenient  
Easy to use  
Highly Concentrated  
Planet friendly  
Limits kitchen clutter

Le **Bâtonnet à vaisselle** est la combinaison parfaite de notre **Beurre à vaisselle** et de notre **Brosse éternelle**, avec le savon semi-solide intégré directement dans la brosse ! Besoin de plus de savon? Tournez simplement le bas de la poignée pour la faire monter. Pour remplacer le savon, retirez simplement la tête de la brosse et ajoutez un nouveau bâton de recharge.

Pratique  
Facile à utiliser  
Fortement concentré  
Respectueux de la planète  
Limite l'encombrement de la cuisine